




Step 1:  
Check Tyre Size





Step 2:  
Consult chart for correct amount to install





Step 3:  
Prepare drum & pump



Step 4:  
Ensure valve is at 12 O' Clock





Step 5:  
Remove valve



Step 6:  
Connect pump





Step 7:  
Begin installation



Step 8:  
Remove pump and replace valve





Step 9:

Drive away!

